AUTO START "OFF" CONDITION FIRE CONFIRMATION (WHEEL HOUSE) (ENGINE ROOM) OPERATE STRAT SWITCH OPERATE START SWITCH ON WATER MIST CENTRAL CONTROL PANEL ON LOCAL OPERATING BOX SYSTEM START LIMIT SWITCH "ON" PROTECTED SELECTION VALVE "OPEN" IN PROTECTED AREA ALARM SOUND "DISCHARGE" INDICATE "PUMP RUN" INDICATE WATER MIST PUMP ON WATER MIST CENTRAL "START" ON WATER MIST CENTRAL CONTROL PANEL CONTROL PANEL FIRE FIGHTING WATER MIST DISCHARGE" FIRE EXTINGUISHING CONFIRMATION (WHEEL HOUSE) (ENGINE ROOM) OPERATE STOP SWITCH ON WATER MIST CENTRAL OPERATE STOP SWITCH ON LOCAL OPERATING BOX CONTROL PANEL SYSTEM STOP WATER MIST PUMP "STOP" AUTO OPERATE MANUAL OPERATE CONFIRMATION TITLE C. H. KANG APP. BY *SEAPLUS* CHK. BY K. C. PARK OPERATING LOGIC CO., LTD. DWG. BY H. K. RYU DATE 2005. 01. 12 DWG NO. WM - 0652 - 072 OF